






M = machine guideway / Maschinenführung

ML = measuring length / Messlänge

OL = overall length / Gesamtlänge

⑤ = beginning of the measuring length / Beginn der Messlänge

$$\longleftrightarrow = 0 \dots ML$$

→ + = direction of motion of the scanning unit for ascending position values

Bewegungsrichtung des Abtastkopfes für steigende Positionswerte

K = customer mounting dimensions / kundenseitige Anschlussmaße

optional / Optionen

P = M5 air inlet / M5 Luftanschluss

S1, S2 = switch signals / Schaltsignale

RI = selectable reference mark / wählbare Referenzmarke

A = connecting cable / Anschlusskabel

* = actuator magnet / Schaltmagnet

** = sensor position / Sensorposition

FX = fixed mounting / festes Befestigungselement

FL = flexible mounting / flexibles Befestigungselement

				ID number: -				
				Change No. C157360-16				
				Phase: Serie				
		Original drawing		MSA730 MSA730 Anschlussmaße / Mating Dimensions				
		Scale Format						
Dimensions in mm	1:1	A2	Tolerances as per ISO 8015					
			General Tolerances ISO 2768:1989-mH ≤ 6:±0.2					
The reproduction, distribution and utilization of this document as well as the communication of its contents to others without express authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design. (ISO 16016)								
 www.rsf.at			Released		Version	Revision	Sheet	Page
			23.11.2023		D 679287-01 - C-01			1 of 1
					Document number			